



## MQTT Out node

Podobne ako sériový port, aj MQTT uzol pozostáva vlastne z dvoch blokov, jeden je viditeľný a slúži na manipuláciu so správou, druhý je konfiguračný a je skrytý. Na obrázkoch je vidno ako vyplniť potrebné údaje na pripojenie k serveru Thingsboard.IO Budete potrebovať ID kľúč, ktorý ste si vygenerovali v Thingsboard.IO pre posielanie dát.

**Edit mqtt out node**

Delete Cancel Done

Properties

Server Thingsboard.io

Topic v1/devices/me/telemetry

QoS Retain

Name Name

Tip: Leave topic, qos or retain blank if you want to set them via msg properties.

**Edit mqtt out node > Edit mqtt-broker node**

Delete Cancel Update

Properties

Name Thingsboard.io

Connection Security Messages

Server demo.thingsboard.io Port 1883

Enable secure (SSL/TLS) connection

Client ID Leave blank for auto generated

Keep alive time (s) 60 Use clean session

Use legacy MQTT 3.1 support

**Edit mqtt out node > Edit mqtt-broker node**

Delete Cancel Update

Properties

Name Thingsboard.io

Connection Security Messages

Username SEM PRIDE VAS KLUC

Password